

Installation & Operating Instructions for DU / DC Series Area, Master & Combination Alarm Systems



Area Alarm



Master Alarm



Combination Alarm



Installation & Operating Instructions for DU / DC Series Area, Master & Combination Alarm Systems

Contents

Features & Benefits	3
Major components	4
Introduction	5
Alarm Panel Installation	6
Rough-In Box Installation	6
Mounting	6
Wiring	7
Plumbing	8
Front David Installation	0
Wiring alarm front to newer supply	9
	10
Installing the Transducers	10
Wiring the transducers	11
Remote transducer wiring	33
Wiring the Remote Devices	12
wining the Kentote Devices	15
Labeling the Alarm Front	14
Alarm Displays & Functions	15
Component identification	16
Button module displays & functions	17
Power on indicator	17
Silence button	17
Test button	17
↑ (up) button	17
↓ (down) button	17
\rightarrow (right) button	17
← (left) button	17
History button	17
View Alarm History	1/
Clear Alarm History	1/
Gas (Area) module displays & functions	19
System LED	19
Pressure LED Digital Display	19
Pressure LED Hi/Normal/Low Display	19
Units of measure LED display	19
Remote Signal (Master) module displays & functions	19
Normal status LED	19
Abnormal status LED	19

Alarm Operation	20
Remote signal (master) module	20
Gas (area) module	20
Silencing the alarm	20
Testing the alarm	20
System alarm/alert & error codes	21
Programming the Alarm	23
Keypad identification	22
Accessing the Program Mode	23
Hi/Low pressure limits	23
Remote Signal Alarm Points	24
Alarm Repeater Delay	24
Units of Measure Display	24
Adjusting the line pressure display	25
Adding/removing modules	25
Board Identification #	25
Adding T-Net [™] Interface Circuit Board Installat	ion26
Adding Building Management (MCP)	
Circuit Boards & Wiring	27
Appendix A Glossary of Terms	28
Appendix B Alarm Specifications	29
Appendix C Signal Wire Color Code Log	30
Appendix D Wiring Diagram	31
Appendix E Source Equipment wiring	32
Appendix F Remote Transducer wiring	33
Terms & Warranty	34
Technical Assistance	_1-888-769-7979



Introduction

The Powerex gas alarm system monitors the status of the medical gas distribution system and provides audible and visual indicators. The master alarm can be furnished with building management interface circuit board(s) to communicate all master alarm/status information to the building management system. The alarm can be used in conjunction with the Powerex T-Net system to monitor the status of all T-Net equipped alarm and manifold systems on a PC. The Powerex alarm system monitors the status of the medical gas sources in accordance with NFPA 99 and CSA Z7396.1

Features & Benefits

- Microprocessor controlled
 - State of the art maintenance free electronics provide excellent reliability.
- Easy to program
- One man adjustable digital pressure display (at the panel, not the transducer)
- Remote signal modules
 - Each circuit board provides monitoring of 16 separate remote devices.
- Self test program alarm code display
 - LED display reveals the nature of the malfunction and reduces maintenance time.
- Three year PC board warranty
- A quality product you can buy with confidence.
- Independent multiple master alarms
 - When service is interrupted to one alarm the other(s) continue to operate independently.
- Transient signal filter
 - Prevents or reduces nuisance (false) alarms signals (less than 0.7 seconds) created by EMI /RFI interference.
- Audio & visual signal indicators
 - Audible alarm and visual display of both normal and abnormal status of each signal monitored assures prompt and informative indication of a problem.
- Optional building management interface circuit board(s) MCP boards
 - Allows communication of remote signals (master alarm points) with building management system.
- Easy to install and service
 - Hinged frame with lanyards for easy accessibility.
- Dry remote signal contacts (high & low) for each

gas module

- Dry contacts are provided so that both the high & low line pressure alarms may be remotely wired to a remote or master alarm.
- Programmable remote signals (Master Module)
 - Configure each remote signal independently (either normally closed, normally open or turn unused signals off).

• Digitized transducers

- Allow remote locating of transducers up to 5,000 feet away from alarm panel. Extremely resistant to RFI.
- Programmable gas module high and low set points
 - Pre-programmed from factory at 60/40 psig for 50 psig delivery pressure gases, 200/140 for N2 and 12 in Hg for Medical Vacuum & WAGD/EVAC. Programmable in 0.5 psig or In Hg increments from 0.5 psig or In Hg up to 30 In Hg or 100 psig or 250 psig (depending on which type of transducer is used).
- Compact unit
 - Requires minimal wall space. Monitors up to 14 area alarm signals or 64 remote (master) signals in one 5 slot panel.
- Alarm history recall
 - Can recall previous alarm signals (both area and master alarms) even after the alarm condition has been corrected and the alarm panel has been cleared.
- Area Alarm repeat feature
 - Adjustable from 1 minute to 240 minutes (factory programmed for 10 minutes.



Installation & Operating Instructions for DU / DC Series Area, Master & Combination Alarm Systems

Major Components



Riser assemblies (for installing transducers in alarm back box) Hinges and screws for attaching front panel to back box

Transducer assemblies



Introduction

The Powerex gas alarm system monitors the status of the medical gas distribution system and provides audible and visual indicators. The master alarm can be furnished with MCP building management interface circuit board(s) to communicate all master alarm/status information to the building management system. The alarm can be used in conjunction with the Powerex T-Net system to monitor the status of all T-Net equipped alarm and manifold systems on a PC. The Powerex alarm system monitors the status of the medical gas sources in accordance with NFPA 99 and CSA Z7396.1.

The Powerex gas alarm system is a two or three section assembly comprised of a rough-in box, a front panel and transducers (only if it is an area alarm or combination alarm).

Rough-in box

The rough-in box houses the power supply, fuse, on/off switch, and a terminal strip for electrical wiring. An isolated transformer reduces the 110V or 220V AC input to low voltage DC.

Front panel

The front panel includes enclosed printed circuit boards with programming circuitry.

The **Push Button module** includes a power on indicator, programming buttons and an audible alarm.

The **Remote Signal module(s)** can monitor up to 16 signals per circuit board. Multiple remote signal modules can be ordered in a single alarm. The signals can be configured to display an abnormal condition on either a normally closed (NC) or a normally open (NO) circuit. Each signal may also be turned off if it is not being utilized.

The **Remote Signal module(s) with MCP** are equipped with all of the above described features as the standard Remote Signal module(s) described above. In addition, the remote signal module(s) with MCP are equipped with an extra set of remote signal dry contacts to interface with a building management system.

The **Gas (Area) module(s)** on the front panel are identified with gas specific, color coded labels (per NFPA 99 or CSA Z7396.1). The gas displays include LED's which indicate high/ normal/low pipeline pressure. A digital LED display shows the actual gas pressure. The gas pressure may be displayed in PSI and In Hg, or BAR or kPa. The unit is pre-programmed to display PSI / In Hg from the factory, but may be re-programmed in the field to display BAR or kPa. In addition there are LED's which illuminate to indicate System and Program failures. Each module is supplied with dry contacts for remote signaling of high and low pipeline pressure.

Transducers

The transducer converts pressure to an electrical signal and supplies the electrical signal to the alarm circuit board Gas module panels. After the initial 24 hour 150 psi standing pressure test (required per NFPA 99) has been completed the pressure/vacuum transducers may be connected to the medical gas pipeline. The transducers may be remotely attached to the piping system at distances up to 5,000 feet using standard 18 gauge stranded twisted pair wire. Powerex recommends mounting the transducers in the zone appropriate zone valve box (utilizing the Powerex E Z Backfeed[™] and E Z Find[™] features) or in the alarm back box. Should a transducer require service or replacement it is considerably more of a safety issue and more time consuming to locate and replace transducers which have been remotely located above the ceiling and eliminates contamination issues – such as having to set up a tent in order to remote ceiling tiles.



Alarm Installation

Installation of the Powerex alarm involves installing the rough-in box, the risers and the transducers (if it is an area alarm or combination alarm) and front panel and making the necessary conduit, plumbing and electrical connections. All installation and testing should be done in accordance with NFPA 99 or CSA Z7396.1.

WARNING: Electrical power intended for the alarm to be installed should be disconnected prior to installation.

WARNING: This device should only be installed by qualified personnel. Installation should not be attempted by anyone not having general experience with the installation of devices of this nature.

Rough-In Box Installation

This is a rough-in box for a combination alarm. Your rough-in box should look the same or similar to this unit. The risers are shipped loose, for protection during shipment, and must be installed. If transducers are to be mounted remotely, it is recommended that they be connected to the DISS demand check valves installed in the corresponding zone valve box equipped with the Powerex E Z Backfeed[™] and E Z Find[™] features.

Refer to the building plans to determine the location of the alarm.

The contractor is to provide rigid mounting that will support the alarm box on both sides. The metal flanges provided on both sides of the rough-in box are to rest against the rigid mounting brackets. Screws (contractor provided) are to be driven thru the holes in the metal flanges into the mounting brackets. Flanges are adjustable to allow for a drywall depth of $\frac{1}{2}$ " to 1 $\frac{1}{8}$ ".

Mount alarm rough-in box so it will be flush or just below the finished wall surface using the adjustment feature on the flanges.





(Side/end view of rough-in back box)



Alarm Installation



The power supply hole is located in the bottom (left side) of the rough-in box. Remove the plaster cover and panel covering the power supply. Remove the plug from the hole. Make conduit connections for wiring from the facility emergency power source.



To remove the power supply cover, loosen the two screws at the top of the cover and slide the cover to the right, then lift the cover over the screw heads. Slide the wiring harness strain relief to the left until it is free from the cover.

Wiring



Use either of the two $\frac{1}{2}$ " conduit knock-outs provided on the lower left side and bottom of the rough-in box to route conduit to supply either 120 or 240 VAC to the power supply. Note: Separate conduit should be used for low voltage wires (use knock outs provided on the top of the box).



Route wires through the power supply conduit installed in the bottom and left side of the rough-in box. Connect the 120 or 240 VAC facility emergency power source electrical wiring to the terminal strip provided on the lower left side of the box. (N = neutral, L = Line (hot), FG = field ground).





The wiring harness will be provided pre-wired to the power supply. If by chance you are replacing a wiring harness, the single green ground wire should be fastened to the screw on the top left corner of the power supply board. The wiring plug in connector (which should contain the rest of the wires), plugs into the connector terminal on the upper left corner of the power supply board. The black wire will be on the top.



This is how the power supply should look when the wiring is completed.

Replace the power supply cover and plaster cover (to protect the unit while the drywall and wall covering work are being done) after wiring is complete.

Plumbing the Riser Extension Tubes



Riser extension tubes

Install the risers in the top of the back box as shown.

After removing the protective plastic caps, connect the riser extension tubes to the gas piping system per NFPA 99. Make sure the drop is for the proper gas service. Using a purge gas to insure cleanliness in the tubes, silver braze the joints. Do not use soft solder. Conduct heat away from the check valves. (A purge kit is required for purge equipment connection to the system). The 150 psi standing pressure test of the piping system must be successfully completed and all pressure removed from the system before connecting the transducers to the system. Attaching transducers without depleting the 150 psi standing pressure first will result in damage to the transducers!

- **Note:** It is recommended that gas piping system tubing be connected from the extension tube to the ceiling for a future or blank gas display even though a transducer is not being installed. Cap the unused tube above the ceiling. This will simplify future expansion.
- **Note:** It is also possible to install the transducers remotely (not in the alarm box). In this type of installation the risers are connected to the gas piping system up to 5,000 feet away from the alarm panel.
- Note: Powerex recommends mounting the transducers either in the zone valve box (remote) in conjunction with the E Z Backfeed[™] and E Z Find[™] products or in the alarm back box not remotely above the ceiling. Should a transducer require service or replacement it is considerably more time consuming to locate and replace or service transducers remotely located above the ceiling.



Installing the Hinges



After the walls are finished, the hinges may be installed onto the rough-in box. The two hinges should be fastened to the lower front edge of the rough-in box using the screws provided. The hinge should rest flat against the surface of the drywall.

Installing the Alarm Front Panel



Slide the rectangular holes cut into the bottom edge of the front panel over the front catch of the hinges. Support the front panel in the open position to attach the lanyards.



Attach the two (left & right side) lanyard cables to the alarm front panel using the screws provided.



Wiring the Alarm Front Panel to the Power Supply



Attach the green ground wire, which is in the wiring harness, to the ground screw on the left corner of the front panel – just in front of the power supply.



Attach the plug connector at the end of the wiring harness to the appropriate connector located at the top left corner of the button module circuit board. The plug should lock into place. The plug can only be inserted one way.



This is how the wiring harness plug connector should look when properly installed on the back of the button module board.

Installing the Transducers (non remote)



After depressurizing the 150 psig standing pressure from the piping system, install the appropriate transducers to the appropriate riser extension tube connectors inside the rough-in box. Hand-tighten then torque lightly with a wrench.



Installing the Transducers (remote)



Transducer assemblies with DISS gas specific fittings have also been provided and, after the 24 hour standing pressure test is completed and normal operating pressure has been restored to the medical gas piping system, they must be connected to the DISS demand valves. Note: maximum mounting distance of each remote transducer is 5,000 feet away from the alarm panel to which it will be wired. Follow the wiring instructions in Appendix F.



The transducers have been designed so that they may be installed in a standard 4''x 4''x 2 1/8'' electrical junction box for added protection.



A panel mount feature has been provided to allow mounting of the transducer using standard 1/2"conduit connections and 4"x -4"x 2 1/8" junction boxes. Note: The DISS nut & nipple will need to be removed to allow installation of the conduit nut and then re-installed using oxygen safe Teflon tape.



Connecting the Transducer Wiring to the Alarm Front Circuit Board



The wire terminal connector on the gas board has six wire connection slots. The two wires from the transducer should be installed in the BLK & WHT SENSOR slots. These are the two slots closest to the center of the gas board (as shown). It is preferred that the black wire be closest to the center of the gas board.



The other four connection slots are for optional remote signals of the low and high line pressure alarms.



The transducer plug may be removed from the gas module to make it easier to install the wires.



Visually verify that the appropriate transducer wire pair has been attached to the appropriate gas module by looking at the front of the alarm panel. If there is not an Error Condition and a System alarm, the proper (matching gas service) transducer has been connected to the gas board.



Wiring the Remote Devices to the Remote Signal (Master) Board



Locate the two banks of 16 terminal connectors on the back of the remote signal (master) board.



There are a total of 32 connection points – two connection points for each remote signal. The pairs are labeled 1 IN thru 16 IN on the circuit board. The NC (normally closed) labeled terminal of each pair is where the signal wire should be landed.



The connector terminal may be un-plugged from the circuit board – to simplify installation of the remote signal wires.



Remote signal #1 – signal wire (white) Remote signal #1 – common wire (black) Remote signal #2 – signal wire (red) Remote signal #2 – common wire (green)

Land the corresponding common wire on the C (common) terminal of each pair of terminal connectors.



Labeling the Alarm Front



After all remote signal (master) wires have been landed, identified & cataloged (using appendix C in this manual), you are ready to apply the remote signal labels. Remove by unthreading the two nylon nuts shown here from the back of the alarm front panel.



The panel will now lift out of the white frame. Provided in the packaging with the alarm front panel is a long white card and a pre-printed sheet of labels for the remote alarm signals. Wash your hands before handling these labels and cards! Apply the labels to the appropriate position on the card using the guide lines on the card. When complete, insert the card into the "Monitored Signals" label pocket of the "Monitored Signals" label.



The gas modules are shipped pre-labeled from the factory. If a gas service is changed to a different gas or added to the alarm, it will be necessary to insert the appropriate label in the pocket of the gas module. The new gas label supplied by Powerex will slide into the gas module label pocket of the gas module label.



A blank label has been provided at the bottom of each gas module for room identification. You may type directly onto this label or apply a pre-printed label. The label supplied by Powerex will slide into the gas module label pocket of the gas module label.



Installation & Operating Instructions for DU / DC Series Area, Master & Combination Alarm Systems



When the labeling is complete, install the plate into the white frame and re-attach with the two nylon nuts.



You are now ready to supply power to the alarm. Restore power to the circuit feeding this alarm panel. The toggle switch on the front of the power supply should be placed in the ON position.



Check the green power LED indicator on the front of the button module. It should be illuminated.



If you haven't already, you are now ready to pressurize the piping system to normal operating pressures. The alarm is shown here with Oxygen & Medical Air at normal operating pressures. All remote signal points (master alarm signals) are shown in normal condition.



Area and Master Alarm Displays & Functions





Alarm Displays & Functions

Button Module

Power on Indicator

The power on indicator (green LED) is illuminated whenever electrical power (120 or 240 VAC) is connected to the alarm and the on/off switch is turned on.

Test Button

When the Test button on the front panel is pressed, the alarm illuminates all segments of all lights and LED's and sounds the buzzer.

Alarm Silence

In the event of an alarm condition an audible alarm sounds. The audible alarm can be silenced by pressing the alarm silence button. The high or low pressure LED or the remote signal LED will remain illuminated until the alarm condition is rectified. If a Gas module (area alarm) had alarmed, depressing the silence button will silence the alarm for approximately 10 minutes (factory setting). After approximately 10 minutes, the audible alarm will sound again.

History Button

The History button may be pressed and held at any time to view alarm history. Viewing alarm history is only active while the History button is pressed, releasing the button returns the alarm to normal operation. Pressing the History Button will display the following:

Gas(Area) Module – If there was an alarm condition for any gas (area) module, the High and/or Low Pressure LEDs will be illuminated. If both the High and Low Pressure LEDs are illuminated, the gas has had both a High and Low alarm.

Remote Signal (Master) Module – If there was an alarm condition for any Remote Signal the Red LED will be illuminated. All other LED's will be off.

Clear Alarm History – To clear alarm History you simply press the History button, hold it down and simultaneously press the Clear button.

↑ (up arrow)

The up arrow may be pressed & held at any time to display the high line pressure alarm set points of the gas module (area) boards. When in the program mode, the up arrow is used to raise the high line pressure alarm set point on gas module (area) boards and to toggle between your choice of Green condition, Red condition or Disabled condition on remote signal (master) boards.

↓ (down arrow)

The down arrow may be pressed & held at any time to display the low line pressure alarm set points of the gas module (area) boards. When in the program mode, the down arrow is used to lower the low line pressure alarm set point on gas module (area) boards and to toggle between your choice of Green condition, Red condition or Disabled condition on remote signal (master) boards.

\rightarrow (right arrow)

The right arrow may be pressed & held at any time to display the gas service for which the gas module (area) board is currently programmed. When in the program mode, the right arrow is used to toggle between the various options of services on the gas module (area) boards and to toggle to the next remote signal point on the remote signal master boards.

← (left arrow)

The left arrow may be pressed & held at any time to display the type of transducer that is connected to each gas module (area) board. The 3 types are 0 - 30 In Hg, 0 - 100 psig and 0 - 250 psig. When the left arrow is pressed "30" will be displayed for a 0 - 30 In Hg transducer, "100" will be displayed for a 0 - 100 psig transducer and "250" will be displayed for a 0 - 250 psig transducer. When in the program mode, the left arrow is used to save the updated programming information. After the changes have been made and the left arrow is pressed three horizontal lines will appear on the digital pressure display of the gas module being programmed or on the programming display for the remote signal (master) board being programmed.



Combination Alarm Displays & Functions





Gas Module (Area Alarms)

Pressure Reading Display

The LED Digital Pressure Display displays the pressure as indicated by the transducer. The gas pressure may be displayed in PSIG/In Hg, BAR or kPa. PSIG and In Hg is the factory setting.

Note: Vacuum & EVAC / WAGD are actually displayed as inches of Hg in the PSI mode. In kPa mode the Nitrogen gas display indicates one tenth of the actual pressure when the pressure exceeds 999 kPa (i.e. 1100 kPa is displayed as 110 and the kPa and (x 10) LED is lit.

Note: Alarm settings are maintained even if power is interrupted.

Units of Measure Indicator

The Units of Measure Indicator illuminates PSIG/In Hg, BAR or kPa (whichever is selected during programming – PSIG and In Hg is factory setting) providing the unit of measure displayed on the LED pressure reading. In the kPa mode the Nitrogen gas display indicates one tenth of the actual pressure when the pressure exceeds 999 kPa (i.e. 1100 kPa is displayed as 110 and the kPa and (x 10) LED is illuminated).

High / Normal / Low Status Lights

Should the line pressure of a gas exceed the programmed alarm set points for low or high line pressure, the corresponding low or high line pressure LED will be illuminated simultaneously with the buzzer sounding to announce an alarm condition has occurred. When the line pressure is neither high nor low it is considered within the normal range and the green Normal LED is illuminated. These indications are relative to the high and low pressure set points which have been programmed into the alarm. These high and low set points should be set in accordance with NFPA 99 and CSA Z7396.1 at \pm 20% of the normal operating pressure.

System LED

Actual Actual

The System LED illuminates in the event of a system problem or malfunction. The following codes will be displayed when a System Error or Failure is detected, or when the History button is pressed:

Code	Error
0	No error (History only)
1	Flash EE corrupt, defaults loaded
2	Sensor: open or broken line
3	Sensor: com timeout, data not
	received when expected
4	Sensor: Noise on line, or data errors
5	Sensor: Gas type/range mismatch
low psig	Low pressure (History only)
high psig	High pressure (History only)

Remote Signal Status LED's (Master Module)

Normal Status Light (Green)

The normal green status light when illuminated signifies that the equipment being monitored is not in an alarm condition.

Abnormal Status Light (Red)

The abnormal status light when illuminated signifies that the equipment being monitored is in an alarm condition.

Note: If no LED is illuminated the remote signal status LEDs have probably been set in the disabled or off position. This can be verified by placing the Remote Signal circuit board in the programming mode and pressing the \rightarrow to view the status of the remote signal point in question or by simply pressing the Test button to verify that the LED's are functional.

Program Mode

When a circuit board is placed in the program mode (see Programming Modules – page 23) the board may be reprogrammed. The brightness level of the circuit boards other than the one in the program mode is decreased. In addition, on Gas Displays (Area Modules) the PGM (Program) LED is illuminated, on Remote Signal Displays (Master Modules) the first Remote Signal point will blink.



Alarm Operation

This section deals with the daily operational aspects of the alarm panel. The Programming The Alarm section covers the procedures to follow in order to configure the alarm if the preprogrammed settings are not appropriate, a module is added or deleted or if the alarm is being incorporated into a T-Net system. After installation has been completed and the alarm has been properly configured, it is ready for operation.

Master Alarm Panels

Remote Signal (Master) Module

With electrical power applied to the alarm, it will monitor the status of the medical gas distribution system and the remote equipment connected to it.

The remote signals (master) module displays (via LED indicators) the normal/abnormal status of the remote equipment connected to the alarm. All alarm panels are pre-programmed upon leaving the factory to monitor normally closed signals (per NFPA 99). In normal operation all active signals will be green. Whenever an abnormal status signal is detected the corresponding green LED will be extinguished and the red LED will illuminate. Simultaneously an audible alarm will sound. Pressing the Silence button silences the audible alarm (the Red LED continues to be lit). The appropriate personnel should be notified immediately of the alarm condition. When the alarm condition has been rectified the Red LED is automatically extinguished and the Green LED illuminates.

Note: Master alarm signals do not repeat – only area (gas) modules are equipped with the Repeater Delay feature.

Silencing the Alarm

Press the Silence button when the alarm is sounding and the alarm will be silenced.

Testing the Alarm

Pressing and holding the Test button initiates a self-test of the alarm. All LED's and seven segment displays will illuminate for as long as the Test button is depressed. In addition the buzzer will sound. If any LED or seven segment display does not illuminate – it is faulty and the circuit board should be replaced. If the buzzer does not sound, it is faulty and the circuit board should be replaced.

Note: The alarms (both Area & Master) are programmed to ignore transient signals that are less than 0.7 seconds in duration.

Area Alarm Panels

Gas Modules

With the electrical power applied to the alarm and the gas systems adequately pressurized, the following indicators are illuminated: 1) the Power On LED, 2) the pressure readings of the gas on each gas display, 3) the Normal LED (green) on each gas display.

If the pressure of one of the gases drops below the programmed low limit setting, the following events take place simultaneously: 1) the Normal LED will be extinguished, 2) the Pressure Low LED (red) will illuminate, 3) an audible alarm will sound.

If the pressure of one of the gases rises above the programmed high limit setting, the following events take place simultaneously: 1) the Normal LED will be extinguished, 2) the Pressure High LED (red) will illuminate, 3) an audible alarm will sound.

Silencing the Alarm

Press the Silence button when the alarm is sounding and the alarm will be silenced.

The area alarm is equipped with a Repeater Delay feature which monitors only the Gas Module (Area) alarms. The Repeater Delay has been factory programmed to make the alarm re-sound every 10 (ten) minutes as long as the alarm condition exists.

Note: Remote Signal (Master) alarms are not monitored by the Repeater Delay.









System Alarm

The audible buzzer will sound, the System Led will illuminate and an Error Code "Err" will be displayed on the digital pressure display when a system failure occurs or the history button is depressed. The System LED and "Err" will illuminate and flash on and off and alternate with a number (per table below) being displayed on the digital display.

Note: If "Err" should be displayed on the Gas Pressure Display of any gas module, this indicates a problem. Some possible problems and corrective actions are:

The transducer is not connected to the Gas Module. To correct, check the transducer connection to the back side of the Gas Module.

A transducer for a different gas service has been connected to the Gas Module. To correct, check the transducer and the Gas Module gas identification labels and make sure they match.

If the above corrective actions do not correct the problem, contact the factory for assistance.

Code	Error
0	No error (history only)
1	Flash EE corrupt, defaults loaded
2	Sensor: Open or broken line
3	Sensor: Com timeout, data not
	received when expected.
4	Sensor: Noise on line, or data errors
5	Sensor: Gas type/range mismatch
Actual Pressure	Low pressure (history only)
Actual Pressure	High pressure (history only)

PGM notification

The PGM (program mode) LED will flash off & on when a gas module circuit board is manually placed in the program mode. It is important to note that while a gas module is in the program mode, it is not monitoring the medical gas pipeline. See the "Programming the Alarm" section of this manual for instructions on programming the gas module.



Programming the Alarm





Programming the Alarm

The alarm has been programmed at the factory prior to shipment. Programming of the alarm may be necessary if:

- The high or low pressure limits for a gas need to be modified.
- A future gas module is being put into service for an added gas service.
- A gas service is being deleted.
- A gas service is being changed.
- A remote signal alarm point needs to be re-configured.
- A remote signal module is being added in the place of a blank module.
- The alarm identification number needs to be changed.
- You wish to change the repeater delay time.
- You wish to change the units of measure from psig and In Hg to either BAR or kPa.
- The alarm panel is being set up on the T-Net system.

Note: Only authorized personnel should program the alarm! It is important to note that while the alarm is in the program mode, it is not monitoring the medical gas system and alarm conditions will not trigger an alarm.

Accessing the Alarm Program Mode

To program the alarm, the circuit boards must be placed individually, one at a time in the program mode. To place a circuit board in the programming mode, the dip switch located on the back side of the circuit board to be re-programmed, must be changed from the "run" to the "pgm" position.

After this is done, the gas module (area) board being reprogrammed will be brighter than the rest of the gas module (area) boards (when viewed from the front) and the yellow "PGM" LED indicator will be flashing to indicate that the alarm is in the program mode and the board which is illuminated more brightly and has the flashing "PGM" LED is ready to be reprogrammed.

The remote signal (master) board being reprogrammed will have the top (first) signal point flashing and the programming display LED's (at the bottom of the board) will illuminate displaying either an "O" (open circuit) or a "C" (closed circuit) or a "d" (disabled).

The programming buttons, located on the front of the alarm, upper left corner (see photo on page 22) may now to be used to make the needed program changes.

When you have successfully accessed the program mode, it is important to note that some of the buttons revert to their subfunctions:

When programming a gas (area) module:

The UP key \uparrow is used to raise the pressure set point and/or to toggle upward thru the list of sub- options.

The DOWN key \downarrow is used to lower the pressure set point and / or

to toggle downward thru the list of sub-options.

The RIGHT key \rightarrow is used to toggle (scroll) thru the list of major options.

The LEFT key \leftarrow is used to SAVE the new programming options after they are selected.

When programming a remote signal (master) module:

The UP key \uparrow is used to toggle between the choices of the green LED or the red LED or both the green & reds illuminated (disabled).

The DOWN key \downarrow is used to toggle between the choices of the green LED or the red LED or both the green & reds illuminated (disabled).

The RIGHT key \rightarrow is used to toggle (scroll) down to the next remote signal point.

The LEFT key \leftarrow is used to SAVE the new programming options after they are selected.

Note: In order to perform any of the following programming features you must first set the alarm in the program mode.

Programming the High & Low Gas Pressure set points

Immediately upon entering a gas module (area) board in the program mode, the high line pressure set point major option is displayed. If the gas module being programmed is a typical 50 psig delivery pressure gas, the board has been pre-programmed at the factory with the high line pressure set point at 60 psig, so the display should show the number 60. If you wish to raise or lower this setting, simply use the up \uparrow or down \downarrow keys to adjust the pressure setting.

After the setting has been changed to the new desired setting, press the LEFT key \leftarrow (SAVE) to save the new setting. Note: if the SAVE \leftarrow LEFT key is not pressed after making the change to the programming and before pressing any other keys, the new setting will not be saved and the alarm will revert to the previously saved setting(s). When the SAVE key \leftarrow is depressed, three horizontal dashes will appear in the display.

Press the \rightarrow key to move on to the low line pressure and repeat the above procedure.

Note: The alarm is designed with a safety feature so that the high and low set points must be at least 0.5 (psig / in Hg), 0.05 (bar) or 5 (kPa) increments apart. The high set point will not be able to be set below the low set point and visa versa.

Programming the Remote Signal (Master) Alarm Points

While in the program mode, the top signal point LED will be blinking. At the bottom of the same remote signal board, the Programming Display LED set will display the contact state for the blinking signal point. "O" = open, "C" = closed and "d" =



disabled. The contact point that is flashing is capable of being reprogrammed. (Note: in compliance with NFPA 99, all contacts are programmed as closed contact equals a normal condition from the factory). If it is necessary to re-program a signal point; press the \rightarrow key to view the next Remote Signal Alarm Point, when the desired Remote Signal (Master) point is flashing, use the \uparrow or \downarrow keys to alter the point to the desired status, after the desired change is achieved, press the \leftarrow to save the change.

Note: Any contact point that has been disabled will have both the green (normal) and red (alarm) LED illuminated only when in the programming mode, to make it easy to identify them. In the normal mode of operation, both LED's of a disabled signal point will not illuminate nor will this signal point trigger an alarm.

Note: When an alarm condition occurs the audible buzzer sounds simultaneously with the corresponding red LED illuminating and the green corresponding LED being extinguished. When the silence button is depressed, the audible buzzer is silenced and remains silenced until another alarm condition occurs. Master alarm signals do not repeat.

Programming the Gas Alarm Repeater Delay

After placing a gas board in the program mode, press \rightarrow until "dLY" is displayed on the digital display of the gas module then let go of the \rightarrow key. A number will be displayed on the digital display. This number is the setting (in minutes) of the repeater delay. Using the \uparrow or \downarrow keys, adjust the repeater delay to the desired length of time (0 – 240 minutes). (Note: the repeater delay is pre-programmed from the factory at 10 minutes – per NFPA 99). To save the change and return the alarm to the normal alarm mode, press the \leftarrow button, then change the dip switch back to the "run" setting. Note: this procedure must be repeated for all gas boards on the alarm panel.

Note: Master alarm signals do not repeat

Note: If a value of 0 (zero) is programmed and saved for any board, the repeater is disabled. If left programmed this way after 72 hours, the board(s) will automatically revert back to the pre-programmed factory setting of 10 minutes.

Programming the Units of Measure Displays

While in the program mode, press the \rightarrow button until "-U-" is displayed on the digital display of the gas module then let go of the \rightarrow key. The letters "PSI" or "bAf" or " PA" will be displayed on the digital display. This is the unit setting that the gas board is set to display. If you wish to alter the unit display, use the \uparrow or \downarrow keys to select the desired unit display, then press the \leftarrow SAVE key. Note: this procedure must be repeated for all gas boards on the alarm panel.

Note: Vacuum & EVAC/WAGD Gas Modules will automatically display in in/Hg when PSI is selected.

Note: The kPa and x10 LED's will both illuminate on all high delivery pressure Gas Modules (i.e. – Nitrogen and Instrument Air) when kPa is selected. Because the Gas Pressure LED Display is only able to display three digits and high delivery pressures viewed in kPa are four digits, the Gas Pressure LED must be read as a four digit number by multiplying the displayed number by ten. I.E. – the Gas Pressure LED Display is displaying 125 in kPa. The pressure should be read as 1,250 kPa (125 x 10).

Adjusting the Digital Line Pressure

The digital line pressure may be adjusted slightly (per the chart below) by following the simple procedure below. This can be done by one person at the alarm panel – no need to open/adjust the transducers!

- 1. Put the gas module you want to adjust into the PROGRAM MODE.
- 2. Using the TOGGLE \rightarrow (right arrow) button go to the CAL mode.
- Use the UP ↑ ARROW button to increase the pressure reading and the DOWN ↓ ARROW to decrease the pressure reading. The adjusted reading will be displayed as the changes are made.
- 4. Press the SAVE button \leftarrow (left arrow) to save the setting.
- You can return to the original calibration setting by pressing CLEAR then press the SAVE button ← (left arrow) while at CAL in the PROGRAM MODE. This should be done if a transducer is ever replaced, as the reading offset will be applied to the new transducer readings.

Range of adjustment:

VAC or EVAC /WAGD ± 0.5 In hg

100 psig transducers ± 2.5 psig

250 psig transducers ± 6.0 psig

Programming the Board Identification

Note: This feature is only used when the alarm is used in conjunction with a Powerex T-Net system.

Note: Each gas and master (remote signal) circuit board must have a unique Identification Number – no two can share the same number.

After placing a gas board in the program mode, press \rightarrow until "Cld" is displayed on the digital display of the gas module then let go of the \rightarrow key. A number will be displayed on the digital display. This number is the board identification # assigned to that circuit board. Using the \uparrow or \downarrow keys, select the desired board identification #. Use the \leftarrow SAVE button when you are finished.

Note: Each gas and master (remote signal) circuit board must have a unique Identification Number – no two can share the same number.



Note: Valid identification numbers are 1 - 999. The alarm is pre-programmed at the factory with 0 (zero) as the zone identification number.

Adding/Removing Modules or Changing the Gas Service of a Gas Board

To remove either a gas board or a remote signal master board from an alarm – you simply need to turn off the power to the alarm panel (using the switch on the outside of the power supply in the back box), unplug the ribbon cable from the board being removed and then turn the power back on. The alarm will automatically reset itself.

To add a remote signal master board to an alarm – you follow the same instructions above.

Note: The following feature is only used if; an additional gas service is being added to an area alarm, a future gas module is being set up for a new gas service or and existing gas module board is being changed to a different gas service.

The gas boards are pre-programmed for a specific gas service from the factory. After placing a gas board in the program mode, it is possible to change the gas service of the board. The following list cross references the number that is actually displayed on the gas board numeric display with the full names of the gases:

Gas # displayed	Gas service	Transducer type	
12	Nitrogen	250	
24	Oxygen	100	
04	Nitrous oxide	100	
08	CO2 or CO2-O2 mix	100	
22	Medical Vacuum	30	
32	Wagd / AGSS	30	
16	Medical air	100	
06	Helium or Heliox	100	
H16	Instrument air	250	
H24	Hyperbaric oxygen	100	
H08	Medium pressure carbon dioxide	100	
SP	Gas mixture	100	
HSP	High Pressure gas mix	250	
3SP	Tri-Gas	100	



T-Net[™] Interface Circuit Board Installation



Powerex DU/DC series alarms may be ordered without T-Net Interface Circuit boards. The T-Net Interface Circuit boards may be installed later.

The toggle switch on the front of the power supply should be placed in the OFF position.





You will be installing one of three types of interface circuit boards, bracket and cable connector; RS485, Ethernet or Wireless. The Ethernet Interface board is shown here left and the Wireless board is shown here right.

Note: Units incorporating the wireless interface circuit board – contains FCC ID OUR-9XTEND. The enclosed device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.



The bracket mounts to the existing flange nut.



The cable must be installed into the socket on the Button Board properly – per the instructions on the cable.

All of the gas boards and remote signal (master boards) will need to be re-programmed with a unique identification number and set up in the T-Net software per the T-Net installation instructions provided with the T-Net software.

The power may now be restored to the alarm. The alarm is fully functional – even if the T-Net software is not yet installed or is out of service.



Building Management Interface (MCP) Board Wiring



Powerex DU/DC series alarms may be ordered with standard remote signal circuit board(s) or with building management interface circuit board(s). The building management interface circuit board(s) may be installed later, replacing the standard remote signal circuit board(s). It is only necessary to install building management interface board(s) in one of the master alarm panels.

The toggle switch on the front of the power supply should be placed in the OFF position.

Output connections – to building management system



Refer to Wiring Remote Devices to Remote Signal (Master) Board page 13 – the building management interface circuit boards (MCP boards) are wired the same way as the standard remote signal circuit boards. The additional two sets of connection terminal are the connection points for the wires outputting the signal information to the building management system.

-Input connections - from remote signal devices





The connector terminals may be un-plugged from the circuit board – to simplify installation of the remote signal wires. There is no need to remove the wires, simply unplug the connectors from the standard remote signal board and plug them back into the new building management interface circuit board. Be certain to match the label on the socket with the label on the plug.

The additional connector terminals are labeled 1 OUT through 16 OUT and are located on the left edge of the new building management interface circuit board. These correspond with the pairs labeled 1 IN thru 16 IN on the right edge of the circuit board.

The NC labeled terminal of each pair is where the signal wire should be landed. The C labeled terminal of each pair is where the common wire should be landed.



Appendix A

Glossary	of Terms
AC	Alternating Current An electric current that reverses direction or polarity at regular intervals.
DC	Direct Current An electric current that flows in one direction. The current can be steady or pulse.
IN Hg	Inches of Mercury A measurement of the force in a gas vacuum system. 1 IN Hg = 3.38 kPa.
КРа	Kilopascals A measurement of the force in a compressed gas system. 1 kPa = .14 PSI
LED	Light Emitting Diode A semiconductor diode that converts applied voltage to light.
NFPA	National Fire Protection Association The National Fire Protection Association is an association engaged in standards development.
NO	Normally Open An electrical circuit in which the switch is normally open. No current flows through the circuit in normal operation. Only when the switch is closed is the flow of current started.
NC	Normally Closed An electrical circuit in which the switch is normally closed. Current flows through the circuit in normal operation. Only when the switch is opened is the flow of current stopped.
PSI	Pounds per Square Inch A measurement of the force in a compressed gas system. 1 PSI = 6.9 kPa
	Transducer

A device that converts pressure into an electrical signal.

V Voltage

Voltage is electrical pressure or force. One volt is equal to the difference of electrical potential between two points on a conducting wire carrying a constant current of one ampere when the power dissipated between the points is one watt.

Transient Signal

An intermittent and brief signal that quickly corrects and returns the alarm to a normal operating mode before monitoring personnel can silence the alarm.



Appendix B

Medical Gas Alarm Specifications				
Operating Ambient Temperature range: +10C(50F) to +50C(122F)				
Storage Tempera	ture: -20C(-4F) to +	+85C(185F)		
AC Input: 120 - 2	40 volts AC - 50-60	Hz		
DC output (to re	mote signal device	s): 5 VDC		
Input Fuse: 5 am	p input AC line fuse	e protects the input wiring to power supply		
Power Consump	tion: 45W maxim	num @ 120 V		
	50 W maxin	num @ 240 V		
Pressure Measur	rement Accuracy:	0-30 inHg transducer +/-1%		
		Vacuum, Gas Evacuation		
		0-100 PSIG transducer +/-1%		
		Oxygen, Nitrous Oxide, Medical Air, Carbon Dioxide		
		0-250PSIG transducer +/-1%		
		Nitrogen		
Dimensions				
Rough-in Box -	- All dimensions are (mounting flange exclu	e in inches and cover the basic box only uded)		
	Two vertical slot p 8.125W x 11.875H	oanel 1 x 4.000D		
	Three vertical slot panel 13.625W x 11.875H x 4.000D			
	Five vertical slot p 19.625W x 11.875	banel SH x 4.000D		
Front Panel –	Two vertical slot p 10.945W x 13.125	banel 5H x 1.250D		
	Three vertical slot 14.870W x 13.125	: panel 5H x 1.250D		
	Five vertical slot p 22.720W x 13.125	banel 5H x 1.250D		
Transducers –	Housing dimensio 1.990W x 1.990H (Length including inlet	ns x 3.625 fittings)		



Appendix C

Signal Wire Color Code Log

Remote Signals

Signal Position #	Remote Signal Label	Signal Wire Color	Common Wire Color

Remote Signals

Signal Position #	Remote Signal Label	Signal Wire Color	Common Wire Color



Appendix D

Wiring Diagram





Appendix E

Source Equipment Wiring Diagram





Appendix F

Remote Transducer Wiring Diagram





Buyer's purchase order is subject to the following conditions of sale:

Powerex Limited Warranty

Warranty and Remedies. (a) Standard Period of Warranty – Parts and Labor. Powerex warrants and represents all Products shall be free from Defects for the first twelve (12) months from the date of shipment by Powerex. During such warranty period, Powerex shall be fully liable for all Defects in the Products (the "Product Defects"), i.e., all costs of repair or replacement, which may include "in and out" charges, so long as the Products are located in the United States or Canada, and the Products are reasonably located and accessible by service personnel for removal. "In and out" charges include the costs of removing a Product from buyer's equipment for repair or replacement.

(b) Additional Period of Warranty – Parts Only (No Labor). In addition to the above, Powerex warrants the products described herein to be free from defects in material and workmanship for forty-eight (48) months from end of Standard Period of Warranty with the exception of any components which are recommended to be replaced in less than sixty months in our Installation/Operation manuals. Within said period Powerex will repair or replace any part or component which is proven to be defective in either material or workmanship. This warranty covers parts only. Labor is not included. This warranty is valid only when the product has been properly installed according to Powerex specifications, used in a normal manner and serviced according to factory recommendations. This warranty does not cover failures due to damage which occurs in shipment or failures which result from accidents, misuse, abuse, neglect, mishandling, alteration, misapplication or damage due to acts of nature.

(c) General. Powerex warrants each Powerex branded Pipeline Accessory (collectively "Products", individually each a "Product") to be free from defects in material and workmanship ("Defects") at the date of shipment. EXCEPT AS SET FORTH BELOW, NO OTHER WARRANTY, WHETHER EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL EXIST IN CONNECTION WITH THE SALE OR USE OF SUCH PRODUCTS. TO THE EXTENT PERMITTED BY LAW, ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED. All warranty claims must be made in writing and delivered to Powerex in accordance with the procedures set forth on its website (www.powerexinc.com), or such claim shall be barred. Upon timely receipt of a warranty claim, Powerex shall inspect the Product claimed to have a Defect, and Powerex shall replace any Product which it determines to have had a Defect; provided, however, that Powerex may elect, upon return of the Product, to refund to buyer any part of the purchase price of such Products paid to Powerex. Freight for returning Products to Powerex for inspection or for shipping warranty parts shall be paid by buyer where permitted by applicable law. Powerex is not responsible for any import fees, taxes, duties, licenses or other fees imposed by any governmental authority upon the production, sale, shipment and/or use of Products covered hereunder. The warranties and remedies herein are the sole and exclusive remedy for any breach of warranty or for any other claim based on any Defect, or non-performance of the Products, whether based upon contract, warranty or negligence.

(d) Coverage. The warranty provided herein applies to Powerex pipeline products only.

(e) Exceptions. Notwithstanding anything to the contrary herein, Powerex shall have no warranty obligations with respect to Products:

- (i) That have not been installed in accordance with Powerex's written specifications and instructions;
- (ii) That have not been maintained in accordance with Powerex's written instructions;
- (iii) That have been materially modified without the prior written approval of Powerex; or

(iv) That experience failures resulting from operation, either intentional or otherwise, in excess of rated capacities or in an otherwise improper manner.

The warranty provided herein shall not apply to: (i) any defects arising from corrosion, abrasion, use of insoluble lubricants, or negligent attendance to or faulty operation of the Products; (ii) ordinary wear and tear of the Products; or (iii) defects arising from abnormal conditions of temperature, dirt or corrosive matter; (iv) any OEM component which is shipped by Powerex with the original manufacturer's warranty, which shall be the sole applicable warranty for such component.

Limitation of Liability. NOTWITHSTANDING ANYTHING TO THE CONTRARY HEREIN, TO THE EXTENT ALLOWABLE UNDER APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL POWEREX BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTAL, PUNITIVE, SPECULATIVE OR INDIRECT LOSSES OR DAMAGES WHATSOEVER ARISING OUT OF OR IN ANY WAY RELATED TO ANY OF THE PRODUCTS OR GOODS SOLD OR AGREED TO BE SOLD BY POWEREX TO BUYER. TO THE EXTENT ALLOWABLE UNDER APPLICABLE LAW, POWEREX'S LIABILITY IN ALL EVENTS IS LIMITED TO, AND SHALL NOT EXCEED, THE PURCHASE PRICE PAID. In the event of breach of any warranty hereunder, Powerex's sole and exclusive liability shall be at its option either to repair or to replace any defective product, or to accept return, transportation prepaid, of such product and refund the purchase price; in either case provided that written notice of such defect is given to Powerex within twelve (12) months from date of shipment to Buyer, that the product is found by Powerex to have been defective at the time of such shipment, that the product has been installed and/or operated in accordance with Powerex's instructions,



that no repairs, alterations or replacements have been made by others without Powerex's written approval, and that Buyer notifies Powerex in writing within fifteen (15) days after the defect becomes apparent and promptly furnishes full particulars in connection therewith; and provided further that in no event shall the aggregate liability of Powerex in connection with breach of any warranty or warranties exceed the purchase price paid for the product purchased hereunder. Powerex may, at its option, require the return of any product, transportation and duties prepaid, to establish any claim of defect made by Buyer. Unless otherwise agreed in writing (a) Powerex will not accept and shall have no responsibility for products returned without its prior written consent, and (b) Powerex will not assume any expense or liability for repairs to products made outside of its plant by third parties. In the event Powerex elects to replace a defective product, costs of installation, labor, service, and all other costs to replace the product shall be the responsibility of Buyer.

Powerex shall not, except as set forth above, be otherwise liable to Buyer or to any person who shall purchase from Buyer, or use, any products supplied hereunder for damages of any kind, including, but not limited to, indirect, special or consequential damages or loss of production of loss of profits resulting from any cause whatsoever, including, but not limited to, any delay, act, error or omission of Powerex. Supplier's repair or replacement of any Product shall not extend the period of any warranty of any Product.

Warranty Disclaimer. Powerex has made a diligent effort to illustrate and describe the Products in its literature, including its Price Book, accurately; however, such illustrations and descriptions are for the sole purpose of identification, and do not express or imply a warranty that the Products are merchantable, or fit for a particular purpose, or that the Products will necessarily conform to the illustrations or descriptions.

Product Suitability. Many jurisdictions have codes and regulations governing sales, construction, installation, and/or use of Products for certain purposes, which may vary from those in neighboring areas. While Powerex attempts to assure that its Products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchase and use of a Product, please review the Product applications, and national and local codes and regulations, and be sure that the Product, installation, and use will comply with them.

Claims. Any non-warranty claims pertaining to the Products must be filed with Powerex within (6) months of the invoice date, or they will not be honored. Prices, discounts, and terms are subject to change without notice or as stipulated in specific Product quotations. Powerex shall not be liable for any delay or failure arising out of acts of the public enemy, fire, flood, or any disaster, labor trouble, riot or disorder, delay in the supply of materials or any other cause, whether similar or dissimilar, beyond the control of Company. All shipments are carefully inspected and counted before leaving the factory. Please inspect carefully any receipt of Products noting any discrepancy or damage on the carrier's freight bill at the time of delivery. Discrepancies or damage which obviously occurred in transit are the carrier's responsibility and related claims should be made promptly directly to the carrier. Returned Products will not be allowed. **UNLESS OTHERWISE AGREED TO IN WRITING, THE TERMS AND CONDITIONS CONTAINED IN THIS LIMITED WARRANTY WILL CONTROL IN ANY TRANSACTION WITH POWEREX.** Any different or conflicting terms as may appear on any order form now or later submitted by the buyer will not control. All orders are subject to acceptance by Powerex.



Notes			