

RetroFit Wall Outlet

Quick Connect Diamond 2 & 3 to
Ohmeda® Diamond or D.I.S.S. Compatible

FEATURES AND BENEFITS

- Accepts Ohmeda Diamond or D.I.S.S. Gas Specific Adapters.
- Pin indexed to prevent interchangeability of gas services.
- Each outlet is cleaned for medical gas service and pressured tested.
- Less than 3 psi (21 kPa) pressure drop through the outlet @ 120 l/min and 50 psig (345 kPa) inlet pressure.



SPECIFICATIONS

The medical gas retrofit wall outlet shall be Ohio Medical Healthcair® Series, Ohmeda Diamond or D.I.S.S. compatible. The latch-valve shall be NFPA® 99 compliant, cleaned for medical gas service and be pressure tested. Each latch-valve shall have less than 3 psi (21 kPa) pressure drop through the outlet @ 120 l/min and 50 psig (345 kPa) inlet pressure. For outlets providing positive pressure gas, the outlet shall be equipped with a primary and secondary check valve, the secondary check valve shall be rated for 200 psi (1,379 kPa) allowing the primary check valve to be removed for service without isolating the entire zone.

Latch-valves shall be gas specific by means of a gas specific indexing pin arrangement. The indexing pins shall be arranged in such a way as to connect the latch-valve assembly only with the specific matching gas back body, preventing interchangeability of gas services.

The latch-valve assembly, which by means of color coding and wording shall identify the specific medical gas service provided by the outlet and shall accept only Ohmeda Diamond or D.I.S.S. type gas specific adapters.

For aesthetic appeal each outlet shall include a one piece chrome trim plate.

Equipment is manufactured in the USA



RetroFit Wall Outlet



RetroFit Kit for diamond 2/3 Rough-in Part Numbers

261220 Rough-in RetroFit Kit Pressure Gas 261221 Vacuum Rough-in RetroFit Kit

RetroFit Kit for diamond 2/3 Latch valve Part Numbers

261170-1	Latch Valve Ohmeda® Oxy	261160-1	Latch Valve D.I.S.S. Oxy
261170-2	Latch Valve Ohmeda Vac	261160-2	Latch Valve D.I.S.S. Vac
261170-3	Latch Valve Ohmeda N ₂ O	261160-3	Latch Valve D.I.S.S. N ₂ O
261170-4	Latch Valve Ohmeda Air	261160-4	Latch Valve D.I.S.S. Air
261170-6	Latch valve Ohmeda WAGD	261160-5	Latch Valve D.I.S.S. N ₂
		261160-6	Latch Valve D.I.S.S. WAGD
		261160-7	Latch Valve D.I.S.S. CO ₂

© 2013 Ohio Medical Corporation.

This document contains information that is proprietary and confidential to Ohio Medical Corporation. Use of this information is under license from Ohio Medical Corporation. Any use other than that authorized by Ohio Medical Corporation is prohibited. Ohio Medical Corporation, Ohio Medical and the Ohio Medical Corporation logo are registered trademarks of Ohio Medical Corporation.

Healthcair is a registered trademarks of Ohio Medical Corporation

Ohmeda is a registered trademark of GE Healthcare Finland OY
NFPA is a registered trademark of National Fire Protection Association, Inc.



Ohio Medical Corporation, 1111 Lakeside Drive, Gurnee, IL 60031

Phone 800-448-0770 / 847-855-0500 - Fax: 847-855-6300

www.ohiomedical.com - www.ohiomedicalparts.com

255408 (Rev. 2) 9/2013