

601AR/CD

MODEL



SHIELDING GAS KIT

MODEL SHOWN:
601Ar-60-58010

DESCRIPTION

The Model 601Ar/CD shielding gas kits are ideal for low amperage MIG welders with built-in wire feeders. Designed to give precise flow-control at an economical price. Includes a 3/16" x 10' inert hose with fittings.

DETAILS

Capacity: Light Duty

Gauges: 50mm ABS plastic

Seat: One-piece encapsulated seat design with internal filter and PTFE Teflon® seat

Body: Brass

Certifications: CGA E-4

Where Used: Gas-shielded welding

Related Items: 3/16" x 10' Inert Hose P/N: 4300138

Weight: 2.6 lbs./ 1.18 kg.



PART #	MODEL #	GAS	FLOW CAPACITY SCFH	COMPENSATED PSIG	MAX. INLET PSIG	SUPPLY PRESSURE GAUGE PSIG	INLET CONNECTION	OUTLET CONNECTION
3000322	601Ar-60-58010	Ar + Mixes	60	(N/A)	3000	4000	CGA 580	3/8" - 18 RH (F)
3000988	601CD-60-32010	CO ₂	60	(N/A)	3000	4000	CGA 320	3/8" - 18 RH (F)

301AR/CD

MODEL



SHIELDING GAS KIT

MODEL SHOWN:
301Ar-58010

DESCRIPTION

The Model 301Ar/CD shielding gas kits include 10' of 3/16" ID approved hose with inert fittings. They feature the Harris time proven 301 flowgauge regulators to give precise control of the most common welding shielding gases up to 60 SCFH.

DETAILS

Capacity: Medium/Heavy Duty

Gauges: 2" Steel

Seat: One-piece encapsulated seat design with internal filter and PTFE Teflon® seat

Body: Brass

Diaphragm: Neoprene

Certifications: UL® listed/CGA E-4

Where Used: Gas-shielded welding and other industrial gas applications

Related Items: 3/16" x 10' Inert Hose P/N: 4300138

Weight: 3.9 lbs./ 1.77 kg.



PART #	MODEL #	GAS	FLOW CAPACITY SCFH	COMPENSATED PSIG	MAX. INLET PSIG	SUPPLY PRESSURE GAUGE PSIG	INLET CONNECTION	OUTLET CONNECTION
4400229	301Ar-58010	Ar + Mixes	60	(N/A)	3000	4000	CGA 580	3/8" - 18 RH (F)
4400231	301CD-32010	CO ₂	60	(N/A)	3000	4000	CGA 320	3/8" - 18 RH (F)